




NUCLEO 64 CONNECTOR




ADC1_IN2/3 (PA2/3): ST-LINK UART2
 ADC1_IN5(PA5): LD2(Nucleo USR LED)

ADC1_IN0 : Ch01
 ADC1_IN1 : Ch02
 ADC1_IN4 : Ch03
 ADC1_IN6 : Ch04
 ADC1_IN7 : Ch05
 ADC1_IN8 : Ch06
 ADC1_IN9 : Ch07
 ADC1_IN10 : Ch08



POWER



I2C




USART3




Sample Package Footprint

Power(Vcc)Selection




Electrode reference




Bridge all three pads of the solder jumper to configure for 2 Electrode operations instead of the 3 electrodes!
 Note: 2 electrodes will give noisier output than 3 electrodes!


Power Supply Noise Filtering



Amp Ref + Driven Right Leg (DRL)




Instrumentation Amp (INA)




Create solder joint on J3 to narrow the Band Pass freqnechn range
 Default: Wide input frequency band, use when recording EMG, EOG
 Configured: Narrow input frequency band, use for EEG, EOG, and ECG

1000x Gain (Bandpass)



Band Pass Filter Configuration (BPFC)



* C8 (BPFC_C) & R3 (BPFC_R) on the back side of the PCB can be used to configure the bandpass filter.
 * Use them to configure output Gain (decrease) & Band (frequency range).

Header pins / Connectors

